

Microbright LED Motif

Indoor/Outdoor Use

Catalogue Nos: LV243003, LV243440

Thank you for purchasing this product. Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product.

This product can be used in complete safety both indoors and outdoors, but please ensure that the transformer is plugged into the mains supply indoors and not outdoors, or in damp conditions.

INSTRUCTIONS FOR USE

- This product consists of non-replaceable LEDs connected in a series and parallel arrangement.
- Remove the product from the packaging taking care not to damage or twist the wires.
- Make sure that the cable is completely unravelled and that there are no snags in the cable.
- To operate, plug the transformer into mains supply, indoors.

LEDs


- Non-replaceable Light Emitting Diodes (LEDs): Rating – 3V 0.024W

TRANSFORMER

- This product is supplied with a DC 3.5V 1.5VA transformer and should only be used with this transformer.

FOR SAFETY'S SAKE

- It is very important that this product is NEVER DIRECTLY connected to the mains supply without the transformer.
- Do not completely cover the LED with decorations and other flammable materials. Ensure adequate airflow around each LED.
- Do not damage the insulation of cable or LED holder.
- Do not secure the wiring of the product with staples or nails.
- Do not close doors or windows on the product as this may damage the wiring insulation.
- Do not lay the cable under carpet or where it can be damaged.
- Ensure that cables are fully unwound and sited where they will not become damaged or present a tripping hazard.
- Do not connect this light set electrically to any other light set.
- Do not connect this product to the mains supply while it is in the packaging.
- Do not allow any plastic part to come into contact with heat or flame.
- Do not unscrew or twist the LED.
- Do not submerge this product in the water (e.g. puddles, guttering and ponds)
- Ensure table top transformers are positioned on flat, stable, heat resistant surfaces.
- Unplug the product when leaving the house, when retiring for the night or if left unattended.
- Do not overload wall sockets. Use different sockets around the house to plug in multiple lights to balance the load.
- For decorative purposes only. Not suitable for use in play by children
- Please retain this information for future reference.



Transformer



Luminaire



For replacement parts email: accessories@premierdec.com

Complies with safety requirements of BS EN 60598



Manufactured and Imported by:
PREMIER DECORATIONS LTD
United Kingdom: HA4 0EJ
EU: Inniscarra, Co Dublin, D24 E029
consumer@premierdec.com