

Festive

Assembly and Usage Instructions for P060213 90cm Infinity Nutcracker

Box Contents:

1 x Infinity light 1x mounting base 1 x Transformer 1 x Pack of outdoor fittings.

Assembly instructions.

Remove the Infinity light out of the packaging, taking care not to damage the item.

1. Remove the protective film covering the Infinity light.
2. Due to product construction, the foam is compressible so You can squeeze the mirrors together at one end / corner (it will not damage) and put the one compressed corner into the base on an angle.
3. Slide the Infinity light fully onto the base. It is very important to make sure the holes in the infinity light and the base are in the same line so required bolts can be fitted.
4. To complete the assembly please follow the separate outdoor instructions provided with this product.
5. To hang this product to your desired surface please follow the below instructions
6. Fixings are not included for the hanging of this item, please note!
7. Please ensure that you use the appropriate fixings for the type of surface you will be hanging the item too.
8. Please take care when using the appropriate fixings in the fixing holes on this product, that you do not damage the mirrored surface.

How to operate:

Plug the transformer into the wall socket and switch on at the socket, the light will come on.

To turn the lights off, switch off at the wall socket. The transformer must be always kept indoor!!

This item is supplied with a timer function.

To Turn the timer on press the clear button allocated on the transformer.

The green light will indicate that the timer function is on

The lights will stay LIT for 6 hours and then switch itself off and remain off for next 18 hours

To switch the timer, function off, press the clear button.

Warnings:

It is very important that this product is NEVER DIRECTLY connected to the mains supply without the supplied transformer.

Keep away from children & pets.

Do not operate this item whilst still in the packaging.

The LED lamps are not replaceable.

The transformer is only suitable for indoor use.

Do not try to connect this set electrically to another set.

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com

Festive

If there is any damage or breakage to the electric wire, please dispose of safely.

Ensure that cables are fully unwound and sited where they will not become damaged or present a tripping hazard.

Do not secure the wiring of this product with staples or nails.

Do not close doors or windows on the product, as this may damage the wiring insulation.

Do not overload wall sockets. Use different sockets around the house to plug in multiple lights to balance the load.

Do not damage the insulation of cable or LED holder.

Do not lay the cable under carpet or where it can be damaged.

Do not completely cover the LED with decorations & other flammable materials. Ensure adequate airflow around each LED.

For indoor and outdoor use.

Care:

Check fittings regularly to make sure they are tight.

Check outdoor fixing cables regularly to make sure they are taut to prevent the item from tipping over.

Remove base and store flat when not in use.

Clean with a dry, clean cloth

Electrical ratings:

Input 230-240V ~ 50HZ

This set operates on- 9.91V AC 10.2W

Transformer rating- 12V AC 12W

Led Bulb rating-3v 0.067a 0.2w



This Symbol indicates that this product is covered by legislation for waste electrical electronic products. When the product has reached the end of its life, please do not dispose of it with general household waste. Consider the environment and take it to a recognised recycling facility.



TRANSFORMER



LIGHTSET

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com