



Assembly and Usage Instructions for: P051505 – 120CM INFINITY NUTCRACKER

BOX CONTENTS

1 X 120CM NUTCRACKER. 1 x TRANSFORMER
1 X MOUNTING BASE (SEE SEPARATE OUTDOOR INSTRUCTIONS SHEET
FOR INCLUDED FITTINGS)

UNPACKING OF ITEM

PLEASE BE CAREFUL WHEN UNPACKING ITEM AND FITTINGS
TAKE EXTRA CARE WHEN CUTTING PACKAGING AWAY FROM THE
TRANSFORMER LEAD, ALWAYS CUT AWAY FROM THE CABLE!
CHECK THAT YOU HAVE ALL PARTS AND FITTINGS FOR OUTDOOR USE
BEFORE YOU ASSEMBLE THE ITEM!
PLEASE RETAIN THE PACKAGING FOR STORAGE

ASSEMBLY INSTRUCTIONS

ON EACH MOUNTING BOARD YOU WILL NOTICE SOME HOLES, YOU
WILL USE THESE TO MATCH UP ON THE INFINITY ITEM WHICH HAS 2
HOLES, PLEASE MATCH THESE HOLES UP ON THE MOUNTING BOARD.
ON THE INFINITY ITEM THERE WILL BE 2 HOLES AT THE BOTTOM OF
EACH SIDE, MATCH THEM UP WITH THE MOUNTING BOARD HOLES.
FIRSTLY YOU NEED TO INSERT THE INFINITY ITEM INTO THE
MOUNTING BOARD MAKING SURE THAT THE HOLES MATCH UP.
IF YOU ARE HAVING DIFFICULTY GETTING THE ITEM INTO THE
MOUNTING BASE, LINE UP THE EDGE OF THE INFINITY ITEM WITH THE
MOUNTING BOARD AND SQUEEZE THE FOAM TOGETHER, THIS SHOULD
THEN ALLOW YOU TO PUSH THE ITEM INTO THE GROOVE IN THE
MOUNTING BOARD FOR A TIGHT FIT.
DON'T FORGET TO MATCH THE HOLES UP.
REPEAT THIS PROCESS FOR THE NEXT SIDE OF THE ITEM.
NEXT USE THE SUPPLIED SCREWS WITH WING NUTS, THESE NEED TO
GO THROUGH THE ITEM AND THE MOUNTING BOARD, ONCE THROUGH,
TIGHTEN THE WING NUTS.
FOR OUTDOOR USE, PLEASE USE THE OUTDOOR INSTRUCTIONS, THESE
ARE ON A SEPARATE SHEET!

OPERATING INSTRUCTIONS

PLUG TRANSFORMER INTO THE WALL SOCKET AND SWITCH ON AT THE SOCKET, THE LIGHTS WILL COME ON.

TO TURN OFF, SWITCH OFF AT THE WALL SOCKET.

WARNINGS

KEEP AWAY FROM CHILDREN AND PETS!

DO NOT OPERATE THIS ITEM WHILST STILL IN THE PACKAGING!

THE LAMPS ON THIS SET ARE NOT REPLACEABLE!

THE TRANSFORMER MUST BE KEPT INDOORS AT ALL TIMES!

DO NOT TRY TO CONNECT THIS SET ELECTRICALLY TO ANOTHER SET!

IF THERE IS ANY DAMAGE OR BREAKAGE TO THE ELECTRIC WIRE, PLEASE DISPOSE OF SAFELY!

THIS LIGHT SET IS SUITABLE FOR INDOOR & OUTDOOR USE!

BE CAREFUL WHERE YOU LOCATE THIS ITEM, DO NOT LEAVE A TRIP HAZARD!

CARE

CHECK FITTINGS REGULARY TO MAKE SURE THEY ARE TIGHT.

CHECK CABLES TO MAKE SURE THEY ARE TAUT TO PREVENT THE ITEM FROM TIPPING OVER.

REMOVE BASE AND STORE FLAT WHEN NOT IN USE.

USE A DRY CLOTH TO CLEAN.

ELECTRICAL RATINGS

INPUT 230-240V ~ 50 HZ

THIS SET OPERATES ON 9.38V AC & 17.5W

TRANSFORMER RATING 12V AC 24W

LED BULB RATING 3V 0.067A 0.2W



Festive Productions Limited

Otters Brook, Ty Coch way,
Cwmbran NP44 7EZ UK
AB Alrik Hedlund – 412 21,
Gothenburg, Sweden

Having difficulty with this
product? Then contact us on
our support email.

www.festive.co.uk

MADE IN CHINA

Please retain these instructions for future reference

P051505 Issue 1

Festive Technical Support



support@festive.co.uk

