

Festive

INSTRUCTION USAGE FOR COLOUR CHANGING GARDEN LIGHTS P066109, P066111

BOX CONTENTS

1 x set of 10 colour changing lights
10 x plastic garden stakes with clip
1 x transformer

ASSEMBLY INSTRUCTIONS

To use as a set of lights no assembly is required, just plug the transformer into main socket.

To use as a garden stake, clasp the plastic clip around the crackle ball plastic and close the clip, the crackle ball will be facing up.

Repeat this for all 10 stakes. Plug the transformer into main socket.

You can connect to 3 sets of lights sets together.

OPERATING INSTRUCTIONS

Place the light in your desired location.

Always plug transformer into wall socket (indoors)

Switch lights on at the socket. The lights will come on. To switch off, switch plug off at the socket.

The lights are supplied with multifunction transformer, each press on a clear button will change the light's function- 11 Function in total.

TIMER FUNCTION: press and hold for approx. 3 seconds the clear button allocated on the transformer.

The green light will come on indicating the timer function is now on. The lights will stay LIT for 6 hours and then switch itself off and remain on OFF mode for next 18 hours. To switch the timer function OFF press and hold the button for 3 seconds.

ELECTRICAL RATINGS

Input 220-240V 50/60Hz.

This set operates on- 30V AC 2W

Transformer rating- 30V AC 6W

LED bulb rating non- replaceable – SMD 3V 20mA 0.06W

Festive Productions Limited

Offers Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com

Festive

CARE INSTRUCTIONS

Wipe clean with a dry cloth.

Always store in dry conditions.

For indoor and outdoor use.

WARNINGS

It is very important that this product is NEVER DIRECTLY connected to the mains supply without the supplied transformer.

Keep away from children & pets.

Do not operate this item whilst still in the packaging.

The LED lamps are not replaceable.

The transformer MUST be always kept indoor.

Do not try to connect this set electrically to another set.

If there is any damage or breakage to the electric wire, please dispose of safely.

Ensure that cables are fully unwound and sited where they will not become damaged or present a tripping hazard.

Do not secure the wiring of this product with staples or nails.

Do not close doors or windows on the product, as this may damage the wiring insulation.

Do not overload wall sockets. Use different sockets around the house to plug in multiple lights to balance the load.

Do not damage the insulation of cable or LED holder.

Do not lay the cable under carpet or where it can be damaged.

Do not submerge the light set in the water.

Do not completely cover the LED with decorations & other flammable materials. Ensure adequate airflow around each LED.



This Symbol indicates that this product is covered by legislation for waste electrical electronic products. When the product has reached the end of its life, please do not dispose of it with general household waste. Consider the environment and take it to a recognised recycling facility.

UK
CA

CE



TRANSFORMER



LIGHTSET

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com