

Festive

Usage Instructions for 270cm Battery Operated Garlands P061202

BOX CONTENTS

Battery operated 270cm Garland

ASSEMBLY INSTRUCTIONS

No assembly needed.

OPERATING INSTRUCTIONS

Once the batteries have been inserted, follow the below instructions!

There are 8 functions cycle through to find desired effect.

ON: Press the button on the front of the battery compartment, the lights come on, the timer is also on, this set will now stay on for 6 hours and then turn off for 18 hours, this repeats daily.

OFF: To turn off, press the button and hold for 3 seconds, the lights go off.

TIMER: Every time switched on or off, will reset the timer, 6 hours on & 18hours off cycle.

CHANGING BATTERIES

Open the 2 clips on the side of the battery compartment.

Following the polarity markings inside the compartment, insert the 3 x AA batteries.

Shut the battery compartment & then push the 2 clips on the compartment until they lock in place.

ELECTRICAL RATINGS

Each set operates on – 4.5V DC 0.09W

LED bulb rating – 3V 0.02A 0.06W

Battery type & voltage – 3 x AA 1.5V DC

CARE INSTRUCTIONS

Wipe clean with a dry cloth.

Always store in dry conditions.

For decorative indoor use only.

WARNINGS

Please read all instructions and warnings before use.

Keep away from children & pets.

Do not operate this item whilst still in the packaging.

The LED lamps are not replaceable.

Remove batteries when not in use.

Festive Productions Limited

Otters Brook

Ty Coch Way

Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,

Gothenburg, Sweden

01633627300

www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com

Festive[★]

Batteries should only be installed by an adult.

Always remove exhausted or dead batteries from the product.

Do not dispose of in fire. Keep away from all sources of heat.

Remove batteries from the product before storage.

Do not short circuit the supply terminals.

Batteries are to be inserted with the correct polarity.

Never mix old and new batteries.

Batteries may explode or leak if misused.

Do not charge non-rechargeable batteries.

If batteries are swallowed seek urgent medical advice.

Ensure that cables are fully unwound and sited where they will not become damaged or present a tripping hazard.

Do not secure the wiring of this product with staples or nails.

Do not close doors or windows on the product, as this may damage the wiring insulation.



This Symbol indicates that this product is covered by legislation for waste electrical electronic products. When the product has reached the end of its life, please do not dispose of it with general household waste. Consider the environment and take it to a recognised recycling facility.



Festive Productions Limited
Otters Brook

Ty Coch Way
Cwmbran, NP44 7EZ

AB Alrik Hedlund-412 21,
Gothenburg, Sweden

01633627300
www.festive.co.uk

MADE IN CHINA



support@festive.co.uk



Support-FPL@hedlundgruppen.com